

1.	Safety Precautions	1
2.	Introduction	2
3.	Specifications	3
3.1	Engine	3
3.2	Fuel System	3
3.3	Ignition System	4
3.4	Cutting Attachment	4
3.5	Special Accessories	4
3.5.1	For User	4
3.5.2	For Service	4
3.6	Tightening Torques	5
4.	Clutch, Chain Drive, Chain Brake and Chain Tensioner	6
4.1	Clutch Drum/ Chain Sprocket	6
4.2	Chain Catcher	7
4.3	Clutch	7
4.4	Chain Brake	8
4.4.1	Checking Function	8
4.4.2	Disassembly	8
4.4.3	Assembly	10
4.5	Front Chain Tensioner	12
4.6	Side Chain Tensioner	12
5.	Engine	13
5.1	Exhaust Muffler/Spark Arresting Screen	13
5.2	Leaking Test	14
5.2.1	Preparations	14
5.2.2	Pressure Test	15
5.2.3	Vacuum Test	15
5.3	Oil Seals	16
5.4	Removing and Installing	18
5.5	Cylinder	18
5.6	Piston	20
5.7	Piston Rings	22
5.8	Crankshaft	22
5.9	Connecting Rod (021 up to Serial No. X 34 944 402)	23
5.10	Decompression Valve	24
6.	Ignition System	24
6.1	Spark Plug Boot	24
6.2	Ignition Lead	25
6.3	Ignition Module	25
6.3.1	Ignition Timing	26
6.3.2	Removing and Installing	26
6.4	Flywheel	27

7.	Rewind Starter	28
7.1	Routine Maintenance	28
7.2	Rewind Spring	28
7.2.1	Replacing	28
7.2.2	Tensioning	29
8.	AV Handle System/ Handle Housing	30
8.1	Annular Buffers	30
8.2	Front Handle	31
8.3	Handle Housing	31
8.4	Switch Shaft	33
8.5	Contact Spring	34
8.6	Throttle Trigger/ Interlock Lever	34
9.	Chain Lubrication	36
9.1	PickupBody36	
9.2	Connector/ Suction Hose	36
9.3	Vent Valve	37
9.4	Worm	38
9.5	Oil Pump	38
10.	Fuel System	39
10.1	Air Filter	39
10.2	Carburetor	41
10.2.1	Leakage Test	41
10.2.2	Removing and Installing	42
10.2.3	Adjustment (except 023 L and USA)	43
10.2.4	Adjustment (023 L and USA)	44
10.3	Tank Vent	45
10.4	Pickup Body	46
10.5	Suction Hose	46
10.6	Manual Fuel Pump	47
10.6.1	Fuel Hoses	47
10.7	Fuel Tank	48
11.	Special Servicing Tools and Aids	50
11.1	Special Servicing Tools	50
11.2	Servicing Aids	52

1. SAFETY PRECAUTIONS

If the chainsaw is started up in the course of repairs or maintenance work, observe all local and country-specific safety regulations as well as the safety precautions and warnings in the owner's manual.

Gasoline is an extremely flammable fuel and can be explosive in certain conditions.

Improper handling may result in burns or other serious injuries.

Warning! Do not smoke or bring any fire or flame near the fuel. All work with fuel must be performed outdoors only. Spilled fuel must be wiped away immediately.

Wash hands thoroughly after every contact with waste oil.

Do not pour waste oil down the drain or allow it to soak into the ground.

Collect waste oil and take it to an official disposal site for environment-friendly disposal.

STIHL®

© 2000 Andreas Stihl AG & Co., Waiblingen

2. INTRODUCTION

This service manual contains detailed descriptions of all the repair and servicing procedures specific to this power tool series. There are separate handbooks for servicing procedures for standardized parts and assemblies that are installed in several STIHL power tool models. Reference is made to these handbooks in the appropriate chapters in this manual.

As the design concept of model 021, 023 and 025 chainsaws is almost identical, the descriptions and servicing procedures in this manual generally apply to all three models. Differences are described in detail.

You should make use of the illustrated parts lists while carrying out repair work. They show the installed positions of the individual components and assemblies.

Refer to the latest edition of the relevant parts list to check the part numbers of any replacement parts needed.

Parts lists on microfiche and CD-ROM are always more up to date than printed lists.

A fault on the machine may have several causes. To help locate the fault, consult the troubleshooting charts for all assemblies in the "Standard Repairs, Troubleshooting" handbook.

Refer to the "Technical Information" bulletins for engineering changes which have been introduced since publication of this service manual. Technical information bulletins also supplement the parts list until a revised edition is issued.

The special servicing tools mentioned in the descriptions are listed in the last chapter of this manual.

Use the part numbers to identify the tools in the "STIHL Special Tools" manual.

The manual lists all special servicing tools currently available from STIHL.

Symbols are included in the text and pictures for greater clarity. The meanings are as follows:

In the descriptions:

- = Action to be taken as shown in the illustration (above the text)


- = Action to be taken that is not shown in the illustration (above the text)

In the illustrations:

➔ = Pointer


➡ = Direction of movement

Service manuals and all technical information bulletins describing engineering changes are intended exclusively for the use of STIHL servicing dealers. They must not be passed to third parties.



Servicing and repairs are made considerably easier if the clamp (1) 5910 890 2000 is used to mount the machine on assembly stand (2) 5910 890 3100 so that one clamp screw engages the

outer 10 mm bore (3) in the assembly stand.



To service the underside of the machine (e.g. remove the oil pump), turn the machine through 180 degrees and mount it so that one clamp screw engages the inner 10 mm bore (1) in the assembly stand.

Note: Pull the hand guard back against the front handle for this purpose.

The powerhead can then be swivelled to the best position for the ongoing repair and this leaves both hands free.

Always use original STIHL replacement parts.

They can be identified by the STIHL part number, the **STIHL** logo and the

STIHL parts symbol .

The symbol may appear alone on small parts.

3. SPECIFICATIONS

3.1 Engine

STIHL single cylinder two-stroke engine with special impregnated cylinder bore

	021	023 L	023	025
Displacement:	35.2 cm ³ 2.15 cu.in	40.2 cm ³ 2.45 cu.in	40.2 cm ³ 2.45 cu.in	45.4 cm ³ 1.8 cu.in
Bore: 40 mm	40 mm 1.57 in	40 mm 1.57 in	42 mm 1.57 in	42,5 mm 1.7 in
Stroke: 28 mm	32 mm 1.10 in	32 mm 1.26 in	32 mm 1.26 in	32 mm 1.26 in
Power output to ISO 7293:	1.5 kW (2.0 bhp) at 9,000 rpm	1.1 kW (1.5 bhp) at 6,500 rpm	1.9 kW (2.6 bhp) at 9,500 rpm	2.2 kW (3.0 bhp) at 10,000 rpm
Max. permissible engine speed (with bar and chain):	11,500 rpm	1) 12,500 rpm	12,500 rpm	13,000 rpm
Idle speed:	2,800 rpm			
Bearings:	Crankshaft supported in heavy-duty ball bearings, needle cages on small and big ends Cylindrical rollers on big end ²⁾			
Piston pin diameter:	10 mm (0.39 in)			
Rewind starter:	Pawl engagement			
Pawls:	Single pawl system			
Reserve pull on rope rotor:	min. 1/2 turn			
Starter rope:	3.0 mm (0.12 in) dia.			
Clutch:	Centrifugal clutch without linings			
Clutch engages at:	3,600 rpm	4,100 rpm	3,500 rpm	3,500 rpm
Crankcase leakage test				
at gauge pressure:	0.5 bar (7.25 psi)			
under vacuum:	0.5 bar (7.25 psi)			

3.2 Fuel System

Carburetor:	Diaphragm carburetor
Standard setting on carburetors with three adjusting screws	
High speed screw H:	Open approx. 1 turn
Low speed screw L:	Open approx. 1 turn
Carburetor leakage test	
at gauge pressure:	0.8 bar (11.6 psi)
Function of tank vent	
at gauge pressure:	≤ 0.3 bar (4.35 psi)
under vacuum:	≤ 0.05 bar (0.725 psi)
Fuel tank capacity:	0.47 l (1 US pt)
Octane rating:	min. 90 RON (US/CAN; pump octane min. 87)
Fuel mixture:	Regular brand name gasoline and two-stroke engine oil
Mix ratio:	50:1 with STIHL two-stroke engine oil 25:1 with other brand name two-stroke, air-cooled engine oils
Air filter: Box filter, fabric or fleece filter	

1) Not adjustable

2) 021 only up to serial number X 34 944 402

3.3 Ignition System	Type:	Electronic magneto ignition (breakerless) with integral trigger unit
	Air gap:	0.2 - 0.4 mm (0.008 - 0.016 in)
	Spark plug (suppressed):	Bosch WSR 6F, NGK BPMR 7 A, Champion RCJ 6Y or Autolite 2984
	Electrode gap:	0.5 mm (0.020 in)
<hr/>		
3.4 Cutting Attachment	Chain lubrication:	Fully automatic speed-controlled oil pump with rotary piston
	Oil delivery rate:	approx. 7.5 cm ³ /min (0.25 fl.oz/min) at 10,000 rpm
	Oil tank capacity:	0.20 l (0.4 US pt)
<hr/>		
3.5 Special Accessories		
3.5.1 For User	STIHL repair kit	1123 900 5000
	3/8" P, 8-tooth rim sprocket kit	1123 007 1001
	.325", 7-tooth rim sprocket kit	1123 007 1003
	.325", 8-tooth rim sprocket kit	1123 007 1002
	1/4", 8-tooth spur sprocket	1123 640 2010
	3/8" P, 7-tooth spur sprocket	1123 640 2000
	.325", 7-tooth spur sprocket	1123 640 2015
	.325", 8-tooth spur sprocket	1123 640 2020
3.5.2 For Service	Side chain tensioner kit	1123 007 1000
	Carburetor parts kit	1123 007 1061

3.6 Tightening Torques

DG screws are used in the polymer and light-alloy components. These screws form a permanent thread when they are installed for the first time. They can be removed and installed as often as necessary without detrimentally affecting the strength of the screwed assembly, providing the specified tightening torque is observed. For this reason it is **essential to use a torque wrench**.

Fastener	Thread	For component size	Torque		Remarks
			Nm	lbf.ft	
Spline screw	IS-DG4x15	Chain brake cover	2.0	1.5	
Spline screw	IS-DG4x15	Handle molding	1.6	1.2	
Spline screw	IS-DG4x15	Connector (engine/oil pump)	2.5	1.8	
Spline screw	IS-DG4x15	Ground wire (to cylinder)	3.5	2.6	
Spline screw	IS-DG5x24	Handle housing/ front handle	3.5	2.6	
Spline screw	IS-DG5x24	Hand guard	3.5	2.6	1)
Spline screw	IS-DG5x24	Hand guard	3.7	2.8	
Spline screw	IS-DG5x24	Fan housing	3.5	2.6	
Spline screw	IS-DG5x24	Buffer (to front handle)	3.5	2.6	
Spline screw	IS-DG5x24	Buffer (to engine)	3.5	2.6	
Spline screw	IS-DG5x24	Ignition module (to engine housing)	4.0	3.0	
Spline screw	IS-DG5.3x40	Cylinder (to engine housing)	9.5	7.0	
Collar screw	DG8x18	Guide bar mounting	16.0	11.8	3)
Collar screw (rear)	DG8x18	Guide bar mounting	8.0	5.9	
	M12x1L	Carrier (clutch)	50.0	37.0	
	M14x1.25	Spark plug	25.0	18.5	
Hexagon nut	M5	Muffler	7.0	5.2	
Hexagon nut	M5	Filter housing/carburetor	2.7	2.0	
Collar nut	M8x1	Flywheel to crankshaft	28.0	21.0	
	M12x1.5	Decompression valve	14.0	10.3	2)
Slotted nut	M5	Filter base/carburetor	2.0	1.5	1)
Spline screw	IS-DG5x16	Spiked bumper	3.7	2.8	

Use the following procedure to fit a DG screw in an existing thread:

- Place the DG screw in the hole and rotate it counterclockwise until drops down slightly.
- Tighten the screw clockwise to the specified torque.


This procedure ensures that the screw engages properly in the existing thread and does not form a new thread, which would weaken the assembly.

- 1) 023 L
- 2) On easy start version only
- 3) With quick chain adjuster


Note: Power screwdriver speed settings for polymer: Plastoform screws max. 600 rpm
DG screws max. 500 rpm

4. CLUTCH, CHAIN DRIVE, CHAIN BRAKE, CHAIN TENSIONER


4.1 Clutch Drum/Chain Sprocket



- Remove the chain sprocket cover.
- Disengage the chain brake by pulling the hand guard toward the front handle.




- Take the needle cage out of the sprocket.
- Clean and inspect the clutch drum/chain sprocket.




- If the clutch drum/chain sprocket is still serviceable, use No. 120 emery paper or emery cloth (grain size approx. 120µm) to clean and roughen its friction surface.

Reassemble in the reverse sequence.




- Remove the E-clip (1).
- Remove the washer (2).



Important: If there are noticeable wear marks on the inside diameter of the clutch drum, check its wall thickness. If it is less than 80% of the original wall thickness, fit a new clutch drum.


Note: If the clutch drum has to be replaced, also check the brake band - see 4.4.2.

- Clean stub of crankshaft. Wash needle cage in clean white spirit and lubricate with grease - see 11.2.
- Replace damaged needle cage.
- Rotate clutch drum/chain sprocket and apply slight pressure at the same time until oil pump drive spring engages properly.
- If rim sprocket was fitted, re-install it with the cavities facing outward.




- Remove the rim sprocket, if fitted.
- Pull off the clutch drum/chain sprocket.

4.2 Chain Catcher




Sprocket cover with integrally molded chain catcher (1).

If the chain catcher has broken off (2), repair as follows:



- Pry the plug out of the front right-hand AV element.




- Oil the cylindrical part (1) of the replacement chain catcher.
- Push the chain catcher into the AV element (2) and engage the peg (3) in the housing bore (4) at the same time.

021, 023, 025


4.3 Clutch

Troubleshooting chart - see "Standard Repairs, Trouble-shooting" handbook.


- Remove the clutch drum/chain sprocket - [see 4.1](#).
- Remove the air filter - [see 10.1](#).
- On 023 L, remove the filter base - [see 10.2.2](#).




- Take out the shutter.
- Pull boot off the spark plug and then unscrew the spark plug.



- Close the decompression valve, if fitted.
- Push the locking strip (1) 0000 893 5903 into the cylinder.




- Unscrew clutch from the crankshaft clockwise (left-hand thread).
- Service the clutch - see "Standard Repairs, Trouble-shooting" handbook.




- Screw on the clutch and tighten down to 50 Nm (37 lbf.ft).
- Install the clutch drum/chain sprocket - [see 4.1](#).

4.4 Chain Brake

4.4.1 Checking Function



- Remove locking strip from cylinder.
- Insert spark plug and tighten down to 25 Nm (18.5 lbf.ft).
- If spark plug has a separate terminal nut, make sure it is properly tightened down.
- Fit boot on the spark plug.



- Fit the shutter so that its lugs engage the recesses in the handle housing.
- Install the air filter - [see 10.1](#).

The chain brake is one of the most important safety devices on the chainsaw. Its efficiency is measured in terms of the chain braking time, i.e. the time that elapses between activating the brake and the saw chain coming to a complete standstill. The shorter the braking time, the better the efficiency and protection offered against being injured by the rotating chain.


Contamination (with chain oil, chips, fine particles of abrasion, etc.) and smoothing of the friction surfaces of the brake band and clutch drum impair the coefficient of friction. This, in turn, reduces the frictional forces and thus prolongs the braking time. A fatigued or stretched brake spring has the same negative effect.

- Start the engine.
- With the chain brake activated (locked), open throttle wide for a brief period (max. 3 seconds) - the chain must not rotate.
- With the chain brake released, open throttle wide and activate the brake manually - the chain must come to an abrupt stop.


Note: The braking time is in order if deceleration of the saw chain is imperceptible to the eye.

4.4.2 Disassembly


- Remove the clutch drum/chain sprocket - [see 4.1](#).
- Release brake spring tension by pushing hand guard forward.
- Remove upper bumper strip from tensioner.




- Take out the screws.
- Remove the cover.




- Carefully ease the brake spring off the anchor pin and take it off the bell crank.




- Pry the brake band out of the engine housing.
- Disconnect brake band from bell crank.



- Take out the screw.



- Remove the washer.




Replace the brake band if:


- there are noticeable signs of wear (large areas on inside diameter and/or parts of outside diameter) and
- its remaining thickness is < 0.6 mm (0.024").

Important! Thickness of brake band must not be less at any point.


- If the brake band is still serviceable, use No. 120 emery paper or emery cloth (grain size approx. 120µm) to clean and roughen its entire friction surface (inside diameter).




- Remove the E-clip.



- Carefully pry the hand guard (1) and bell crank (2) off their pivot pins and lift away together.
- Pull the bell crank out of the hand guard.




- Remove strap from bell crank pivot pin (1).
- Push the strap sideways and lift it off the hand guard pivot pin (2).




- Up to serial number X 28 310 254, remove the spring (1).
- Pull out the cam lever (2).

4.4.3 Assembly




- From serial number X 28 310 255, remove the flat spring.
- Inspect parts and replace if damaged.
- Clean the entire housing recess for the chain brake.
- If the groove of the brake spring anchor pin is worn, replace the housing.


- Lubricate sliding and bearing points of chain brake with STIHL multipurpose grease or, preferably, Molykote grease - see 11.2.
- From serial number X 28 310 255, install the flat spring.




- Up to serial number X 28 310 254, fit the cam lever.
- Attach spring to cam lever (open side of spring hook facing outwards) and slip it over the pivot pin




- Insert the bell crank in the side of the hand guard so that the short arm of the bell crank points to top of hand guard.




- Position the hand guard (1) against the pivot pin and fit the other side of the hand guard over the housing.
- Position the bell crank (2) against the pivot pin.
- Press the cam lever (3) slightly downward and push the hand guard and bell crank onto their pivot pins.




- Check that cam lever or flat spring (1) is properly located on face (2) of hand guard bearing boss.




- Fit the washer on the pivot pin.




- Hook the brake spring onto the bell crank.




- Use the assembly (2) 1117 890 0900 to attach the brake spring (1) to the anchor pin.




- Fit strap on the pivot pin (1) and locate it in the pivot pin's groove.
- Slip the other end of the strap over the bell crank pivot pin (2).
- Secure strap with E-clip.
- Coat brake band with chain oil (STIHL Bioplus), [see 11.2](#), to protect it from corrosion and help reduce "snatching" during the first few brake applications.



- Position the brake band around the clutch and push it into the engine housing.




- Fit the bushing in the hand guard.
- Insert M5x24 screw and tighten down to 3.5 Nm (2.6 lbf.ft).
- On 023 L, push the rubber bushing (1) into the hand guard (2).
- Insert M5x32 screw (3) and tighten down to 3.7 Nm (2.8 lbf.ft).
- Fit the cover.
- Tighten screws to 2.0 Nm (1.5 lbf.ft).
- Install clutch drum/chain sprocket - [see 4.1](#).
- Check operation of chain brake - [see 4.4.1](#).




- Attach the brake spring to the bell crank.

4.5 Front Chain Tensioner




- Remove the chain sprocket cover.
- Pull the cover out of the engine housing.




- Unscrew the nut (1) from the adjusting screw (2).
- Take the adjusting screw out of the cover (3).

Reverse the above sequence to install the chain tensioner.


4.6 Side Chain Tensioner




- Remove the chain sprocket cover.
- Take out the screw.
- Pull the complete tensioner assembly out of the engine housing.



- Take the thrust pad (1) off the adjusting screw (2).
- Rotate the spur gear (3) until the adjusting screw comes out of the tensioner slide (4).



- Pull the spur gear out of the cover.



- Pull the tensioner slide off the cover.
- Take the adjusting screw out of the cover.

- Inspect the teeth on the spur gear and adjusting screw. Replace both parts if necessary.

Reverse the above sequence to install the chain tensioner.

- Coat teeth of adjusting screw and spur gear with grease, [see 11.2](#), before refitting.

BUY NOW

**Then Instant Download
the Complete Manual
Thank you very much!**