

SETTING INSTRUCTIONS FOR SEIKO H558-5009 MOVEMENT



This watch has three different time zones:

- Analog time.
- Digital time.
- Second digital time (local-time), displayed with "-L" in the right corner of the display.

These work independently, the alarm and hourly chime always refer to the digital time.

ANALOG TIME SETTING

- Unscrew the crown and pull it out to position 3 when the second hand is at 12 o'clock
- Turn the crown to set the desired HOUR and MINUTES.
- In accordance with the time signal or SECONDS digits "00" in the DIGITAL TIME display, push the crown in.
- Screw the crown in to the normal position

DIGITAL (DISPLAYS) SETTING

- Push button B until the time is on the display.
- Unscrew the crown. Pull crown to position 2.
- In the TIME display, turn the crown clockwise/counterclockwise to set the HOUR and Minutes digits
- To set SECONDS to "00", press "B" in accordance with the second hand at 12 o'clock position.
- Each pulling out (1st click) and pushing back the crown changes 12/24-HOUR INDICATIONS alternately.


- Note:**
1. When the SECONDS read any number from "30" to "59" and "B" is pressed, one minute is added.
 2. Check that "A" (AM)/"P" (PM) is set properly.
 3. The digits change quickly when the crown is turned fast.

ALARM TIME SETTING

- In the ALARM display, turn the crown to set the desired HOUR and MINUTES.
Note: Check that “A” (AM)/”P” (PM) is set properly.

Switch alarm and hourly chime on/off.

With each pulling out (1st click) and pushing back the crown in the ALARM display, the alarm and hourly time signal appear and disappear in the following sequence.

	Alarm	Hourly chime
Off	Off	Off
On	On	Off
Blinking	On	On

LOCAL TIME SETTING

- In the LOCAL TIME display (“L” mark appears), turn the crown to set the desired HOUR and MINUTES.
- Each pulling out (1st click) and pushing back the crown changes 12/24-HOUR INDICATIONS alternately.

CALENDAR SETTING

- In the CALENDAR display, turn the crown clockwise to set MONTH and DATE
- Turn the crown counter clockwise to set DAY of the week
- Only the DAY and DATE appear when the crown is at normal position

After all adjustment are completed, screw the crown in to the normal position.

STOPWATCH

- Press “B” to show the STOPWATCH display.
 - The stopwatch can measure up to 60 minutes. After 60 minutes, it will start counting again from “00:00oo”.
1. Standard measurement:
 - To start: Press “A”
 - To stop: Press “A”
 - To reset: Hold “A”
 2. Accumulated elapsed time measurement
 - To start: Press “A”
 - To stop: Press “A”
 - To restart: Press “A”
 - To stop: Press “A”

Light.

- Push button A to illuminate the digital display. Does not work in stopwatch mode.

Alarm test.

- Push buttons A and B simultaneously to sound the alarm.